## NSN 5985-00-431-6141

Waveguide Assembly - Page 1 of 1



View Online at https://aerobasegroup.com/nsn/5985-00-431-6141

Flores Oversites
Flange Quantity:
2
Voltage Standing Wave Ratio:
1.10
Insertion Loss In Decibels:
0.10
Waveguide Longer Offset Distance:
Between 6.510 inches and 6.540 inches
Waveguide Offset Distance:
2.137 inches
Flexibility:
Rigid single tubing segment
Style Designator:
Bend type
Shelf Life:
N/a
Unit Of Measure:
Demilitarization:
Yes - demil/mli
Fiig:
A073a0