

View Online at <https://aerobasegroup.com/nsn/1430-01-326-9934>

**End Application:**

Acm se

**Special Features:**

Continuity test of the impact sensor assembly is required to impact sensor test; a pre-power static manually measure the impact sensor loop and the ordnance alarm loop circuit continuity. The impact sensor loop continuity resistance is not to exceed 2.0 ohms. The ordnance alarm loop continuity resistance is not to exceed 1.0 ohm.Afm-124

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

Yes - demil/mli

**Fiig:**

A23900