

View Online at <https://aerobasegroup.com/nsn/3510-00-892-6125>

**Speed Adjustments:**

Multiple

**Current Type:**

Ac

**Prime Mover Type:**

Electric motor

**Err Default:**

Err default or err default

**Loading Location:**

Side or top

**Extraction Method:**

Centrifugal

**Err Default:**

Err default

**Drain Type:**

Pump

**Operating Control Type:**

Automatic

**Voltage In Volts:**

220.000

**Phase:**

Single

**Frequency In Hertz:**

50.000

**Specification Or Standard:**

1 type and 3 class and b style

**Departure From Cited Document:**

As modified by voltage in volts, frequency in hertz

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fig:**

T155-c