

View Online at <https://aerobasegroup.com/nsn/4140-01-302-7486>

Mounting Facility Type And Quantity:

1 rack

Err Default:

Err default

Special Features:

Used to move free-flowing air over a wide, crossflow, range

Functional Description (non-core):

Used to move free-flowing air over a wide, crossflow, range

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

A087a0