

View Online at <https://aerobasegroup.com/nsn/4820-00-394-7761>

Flow Control Device:

Stem

Bonnet Type:

Outside screw-yoke

Bonnet Attachment Method:

Bolted

Connection Style:

Socket (tube) err-100

Valve Operation Method:

Manual

Connection Type:

Unthreaded internal tube all ends

Mounting Facility:

Bracket

Outside Diameter Tube Accommodated:

0.625 inches all ends

Special Features:

Stem extends 9.000 in. Between valve body and valve bonnet, clean in accordance w/mil-c-52211

Material:

Steel stem

Style Designator:

Angle

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fig:

A046b0