

View Online at <https://aerobasegroup.com/nsn/4820-00-626-4360>

Flow Control Device:

Cone

Bonnet Type:

Inside spring

Bonnet Attachment Method:

Integral

Disk Loading Method:

Spring

Connection Style:

Socket (tube) err-100

Valve Operation Method:

Air

Connection Type:

Unthreaded internal tube all ends

Mounting Facility:

Bracket

Outside Diameter Tube Accommodated:

0.750 inches all ends

Material:

Steel flow control device

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

A046b0