

View Online at <https://aerobasegroup.com/nsn/4820-01-278-5422>

Flow Control Device:

Disk

Bonnet Type:

Inside spring

Bonnet Attachment Method:

Union

Disk Loading Method:

Spring

Connection Style:

Socket with brazing ring (tube) err-100

Valve Operation Method:

Automatic

Connection Type:

Unthreaded internal tube all ends

Opening Pressure Setting:

22.0 pounds per square inch

Outside Diameter Tube Accommodated:

1.000 inches all ends

Material:

Stainless steel stem

Media For Which Designed:

Air single response

Style Designator:

Err-090

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

A046b0