

View Online at <https://aerobasegroup.com/nsn/4820-01-315-2562>

Flow Control Device:

Disk

Bonnet Type:

Inside spring

Bonnet Attachment Method:

Bolted

Disk Loading Method:

Spring

End Application:

Los angeles class ss (688)

Connection Style:

Socket with brazing ring (tube) err-100

Valve Operation Method:

Automatic

Connection Type:

Unthreaded internal tube all ends

Outside Diameter Tube Accommodated:

0.250 inches all ends

Material:

Nickel alloy stem

Style Designator:

Err-090

Furnished Items And Quantity:

2 nut and 2 tailpiece

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

A046b0