

View Online at <https://aerobasegroup.com/nsn/4820-01-321-1791>

Flow Control Device:

Disk

Bonnet Type:

Inside screw

Bonnet Attachment Method:

Threaded

Connection Style:

Socket with brazing ring (tube) err-100

Valve Operation Method:

Automatic

Connection Type:

Unthreaded internal tube all ends

Adjustable Pressure Range:

+65.0/+100.0 pounds per square inch

Outside Diameter Tube Accommodated:

0.500 inches all ends

Material:

Copper alloy body

Style Designator:

Err-090

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

A046b0