

View Online at <https://aerobasegroup.com/nsn/4910-01-366-9436>

Functional Description:

Used for disassembly and assembly of unit injectors and to check assembled injectors for free rack movement

Reference Data And Literature:

Caterpillar publication, engine tools, 12-89 fuel injection pumps and valves, group 9, pg 2-171

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fig:

A505c0