

View Online at <https://aerobasegroup.com/nsn/4910-01-366-9436>

**Functional Description:**

Used for disassembly and assembly of unit injectors and to check assembled injectors for free rack movement

**Reference Data And Literature:**

Caterpillar publication, engine tools, 12-89 fuel injection pumps and valves, group 9, pg 2-171

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fig:**

A505c0