

View Online at <https://aerobasegroup.com/nsn/4920-01-303-4208>

Functional Description:

The fairing torque box fixture is used on the lower wing fairings; used during testing; repairing/recondition; handling; removal/replacing on the b1-b acft

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

A505c0