

View Online at <https://aerobasegroup.com/nsn/4920-01-303-4208>

**Functional Description:**

The fairing torque box fixture is used on the lower wing fairings; used during testing; repairing/recondition; handling; removal/replacing on the b1-b acft

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fiig:**

A505c0