

View Online at <https://aerobasegroup.com/nsn/4920-01-344-3564>

**Test Item Connection Method:**

Connector

**Functional Description:**

Provide the required electrical and mechanical interface between the unit under test (utt) and the test station; the load box, test package, analog modules, radar is used to connect the lru and sru to the test station

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

Yes - demil/mli

**Fig:**

A537k0