## NSN 4920-01-460-0249

Interface Assembly - Page 1 of 1



View Online at https://aerobasegroup.com/nsn/4920-01-460-0249

P	r۸	Ы	 ct	N	ai	m	۵.

Alr-66 interface assembly

## **Functional Description:**

The interface unit is part of the test harness (which includes the interface unit, a test harness subassembly and an isolation transformer) this e quipment is used to verify and isolate faults to a specific Iru of the rwr system, and can be used for training operators and maintenance personnel in the avionics shop

_				
c	hο	JIF.		ife:
J	116		_	HG.

N/a

**Unit Of Measure:** 

--

Demilitarization:

Yes - demil/mli