Guided Missile Components Maintenance Stand - Page 1 of 1



View Online at https://aerobasegroup.com/nsn/4935-01-268-4719

Mounting Type:

Floor

Special Features:

Used on Igm-118 peacekeeper

Supplementary Features:

Used to support the air elevator and gain access to the top & inside of the air elevator for performing maintenance on the air elevator

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

Yes - demil/mli

Fiig:

T361-b