

View Online at <https://aerobasegroup.com/nsn/5120-01-187-5717>

Special Features:

Used during depot level maintenance of the air vehicle engine to remove the spinner; it is installed with the puller fingers engaged in the 3 holes in the spinner housing; the threaded shaft is turned down onto the I.P. Shaft and the spinner is drawn off the shaft

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

T294-m