

View Online at <https://aerobasegroup.com/nsn/5120-01-379-9485>

Functional Description:

Rquired to remove and install bearings on the cenc mount bracket. Also used to install and remove bearings from the rcvv, civv, bleed strap, and cenc bracket links, rod ends, and control arms. Turbo fan engine f100-220

Reference Data And Literature:

Serd 6399

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fig:

T294-m