

View Online at <https://aerobasegroup.com/nsn/5120-01-379-9485>

**Functional Description:**

Required to remove and install bearings on the cenc mount bracket. Also used to install and remove bearings from the rcvv, civv, bleed strap, and cenc bracket links, rod ends, and control arms. Turbo fan engine f100-220

**Reference Data And Literature:**

Serd 6399

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fig:**

T294-m