

View Online at <https://aerobasegroup.com/nsn/5120-01-381-5396>

General Description:

Used to flare the clinch nut when the nut is assembled to the turbine exhaust case and the augmentor nozzle support assemblies; after the clinch nut is positioned into the flang hole, the anvil and pin end of the tool is placed into the threaded end of the nut and tapered end of tool is placed into the end of nut to be flared. Knob on end of tool is rotated to create flare. Agavgf100-220

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No