

View Online at <https://aerobasegroup.com/nsn/5120-01-381-5396>

**General Description:**

Used to flare the clinch nut when the nut is assembled to the turbine exhaust case and the augmentor nozzle support assemblies; after the clinch nut is positioned into the flange hole, the anvil and pin end of the tool is placed into the threaded end of the nut and the tapered end of the tool is placed into the end of the nut to be flared. Knob on end of tool is rotated to create flare. Agavgf100-220

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No