

View Online at <https://aerobasegroup.com/nsn/5120-01-385-7599>

End Application:

Engine assembly tf117 pw100

Special Features:

During assembly and disassembly, the mount bushing must be installed or removed from the oil tank flange; due to a tight fit, a mechanical force is required to remove or install the bushing

Functional Description:

Lpwa81854 pusher/puller consists of a steel shaft, a collar nut, a cylindrical pusher, and a stop; the shaft has a hex machined on the end, a flanged body, and a threaded end; the shaft and pusher are assembled together; the shaft passes through the engine bushing; the stop and nut are assembled on the opposite end of the shaft; tightening the nut creates the force to remove or install the bushing; the pusher can be inverted depending on assembly or disassembly operation

Fsc Application Data:

Pusher/puller - oil tank assembly bushing replacement

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

T294-m