

View Online at <https://aerobasegroup.com/nsn/5210-01-526-0998>

**End Application:**

Master, inspection-3rd and 4th stage turbine disk

**Criticality Code Justification:**

Feat

**Special Features:**

The inspection master is used to zero the pwa500519 inspection gage. The pwa500517 and pwa50018 constraint fixtures are used to constrain the 3rd and 4th stage turbine disks during dimensional inspection of the snap diameters. "caution" the equipment used to measure the turbine disk diameters are precision instruments. Do not drop or damage the equipment. Ensure that equipment hardware is secure. Serd 9863

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fiig:**

T299-t