

View Online at <https://aerobasegroup.com/nsn/5840-01-086-8274>

General Description:

The unit is the transmitter portion of the antenna-transceiver unit. It is located inside the transceiver enclosure. The unit consists of two major subassemblies, the amplifier-high voltage subassy and the low voltage subassy. The amplifier-high voltage subassy is located on the fwd side of the trailer and the low voltage subassy is located along the curb side of the unit. The components which comprise the amp-hv subassy are mounted on a 56.25 in.L by 24.13 in. Height panel. The components which comprise the lv subassy are mounted on a 28.13 in.L by 24.13 in. Height panel. The unit generates electrical signals of specified frequency and form to generate electromagnetic waves when applied to the antenna

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

Yes - demil/mli