

View Online at <https://aerobasegroup.com/nsn/5895-01-550-7688>

**Special Features:**

Mfr description; the excap is the operator interface to the intercommunication system. It enables the user to select navigation and communications assets for monitoring and transmitting. It also allows selection of the intercom to communicate with other crewmembers. It has volume controls (both master and for individual assets), hot mic and vox selection, vox level and a call button which permits connection to all crewmembers on the aircraft at full volume for alert messages. Backup mode can be selected which connects vital assets directly to the flightdeck excap's if there's a power failure or a fault in the icu

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

Yes - demil/mli

**Fiig:**

A31700