

View Online at <https://aerobasegroup.com/nsn/5895-01-601-3307>

Basic Shape Style:

Rectangular or square

Inclosure Type:

Encased

Operating Control Method:

Automatic

Control Type:

Local

Connection Type And Location:

Terminal block w/screw top

External Dc Operating Voltage In Volts:

12.0 1st voltage

Product Name:

Two-channel rs-485/rs-422 to current loop converter

Special Features:

The rs-485/rs-422 driver is enabled automatically when data is received on the current loop side of the converter; driver is disabled 8.33 milliseconds, one character at 1200 baud, after data transmission is complete; current loop side of the converter has a female db-25s connector

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

Yes - demil/mli

Fiig:

A32200