

View Online at <https://aerobasegroup.com/nsn/5905-01-202-4950>

**Section Quantity:**

1

**Reliability Indicator:**

Not established

**Maximum Starting Torque:**

5.00 inch-ounces

**Maximum Running Torque:**

5.00 inch-ounces

**Mounting Method:**

Terminal

**Electrical Resistance Per Section:**

5.000 kilohms single section

**Resistance Tolerance Per Section In Percent:**

-10.0/+10.0 single section

**Actuator Travel Control Feature:**

Stops

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fig:**

A002a0