Radio Frequency Transformer - Page 1 of 1



View Online at https://aerobasegroup.com/nsn/5950-00-583-4497

|        | bility Indicator:                                     |
|--------|---|
|        | stablished  |
|        | former Function:                                      |
| Inters |   |
| -      | ency Rating:  |
|        | kilohertz single component                            |
| -      | tment Device Drive Type:                              |
|        | d screw single component                              |
| -      | Length:   |
|        | inches  |
|        | Width:  |
|        | inches  |
| -      | Height:   |
|        |   |
|        | sure Type:  |
| -      |   |
|        | ting Facility Quantity:                               |
| -      | le group  |
|        | ting Method:  |
|        | e single group and threaded hole single group         |
|        | ing Function And Quantity:                            |
|        | ary single component and 1 secondary single component |
|        | d Size:   |
|        | inches single group                                   |
| -      | tment Method And Quantity:                            |
|        | Istable core single component                         |
|        | d Series Designator:                                  |
|        | ingle group   |
|        | nal Type And Quantity:                                |
|        | er stud   |
| Shelf  | Life:   |
| N/a    |   |
| Unit C | Of Measure:   |
|        |   |
|        | itarization:  |
| No     |   |
| Fiig:  |   |
| A058b  | 00  |