Radio Frequency Transformer - Page 1 of 1



View Online at https://aerobasegroup.com/nsn/5950-00-918-8334

Reliability Indicator:
Not established
Turn Quantity:
10 single component single primary output
Coil Form Type:
Hollow single component
Adjustment Device Drive Type:
Slotted screw single component
Inclosure Type:
Open
Mounting Method:
Threaded bushing single group
Winding Function And Quantity:
1 primary, variable autotransformer type single component
Adjustment Method And Quantity:
1 adjustable core single component
Terminal Type And Quantity:
3 tab, solder lug
Shelf Life:
N/a
Unit Of Measure:
Demilitarization:
No
Fiig:
A058b0