

View Online at <https://aerobasegroup.com/nsn/5950-01-284-6745>

Reliability Indicator:

Not established

Adjustment Device Drive Type:

Shaft single component

Inclosure Type:

Open

Mounting Method:

Threaded bushing single group

Adjustment Method And Quantity:

1 adjustable core single component

Terminal Type And Quantity:

2 wire lead

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fig:

A058b0