

View Online at <https://aerobasegroup.com/nsn/5950-01-319-0443>

Reliability Indicator:

Not established

Overall Length:

Err-060

Center To Center Distance Between Mounting Facilities Parallel To Length:

Err-060 single mounting facility single center group

Center To Center Distance Between Mounting Facilities Parallel To Width:

Err-060 single mounting facility single center group

Overall Height:

Err-060

Overall Width:

Err-060

Mounting Hole Diameter:

Err-060 single group

Frequency Rating:

Err-060 single component or err-060 single component

Input-output Phase Relationship:

Three phase to three phase single component

End Application:

Crv-msk-5ss low frequency power amplifier

Inclosure Type:

Fully enclosed

Mounting Facility Quantity:

4 single group

Mounting Method:

Unthreaded hole single group

Winding Function And Quantity:

Err-060 single component and err-060 single component

Winding Operating Current:

58.8 amperes dc single component all secondary

Winding Operating Voltage:

Err-060 single component single primary and err-060 single component single primary

Terminal Type And Quantity:

12 threaded stud

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fig:

A058b0