

View Online at <https://aerobasegroup.com/nsn/6110-01-015-8939>

General Description:

Xthree ground posts are located on the rear panel, output lo, secondary shield-chassis, and primary shield. The primary shield on the transformer is connected to the grounding pins on the power input plug, and to the primary shield post

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

Yes - demil/mli