

View Online at <https://aerobasegroup.com/nsn/6110-01-015-8939>

**General Description:**

Xthree ground posts are located on the rear panel, output lo, secondary shield-chassis, and primary shield. The primary shield on the transformer is connected to the grounding pins on the power input plug, and to the primary shield post

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

Yes - demil/mli