

View Online at <https://aerobasegroup.com/nsn/6625-00-855-1526>

**Indicator Type:**

Dial w/pointer

**Installation Design:**

Rack

**Functional Description:**

Direct reading voltage measurements of total, fundamental, in phase, and quadrature components of an ac signal as well as phase angle to 1 deg; -c signal and reference isolation, rear connectors, and 10 mv full scale range

**Supplementary Features:**

Also known as four frequency phase angle voltmeter

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fiig:**

A310a0