

View Online at <https://aerobasegroup.com/nsn/6625-01-211-5455>

Reliability Indicator:

Not established

Scale Division Quantity:

4 single indicator single range

Indicator Type:

Dial w/pointer

Installation Design:

Panel

Accuracy In Percent:

-2.0/+2.0 at full scale single indicator single range

Measurement Range:

+0.0/+150.0 amperes, ac single indicator single range

Operating Voltage Rating In Volts:

100.0 ac

Fsc Application Data:

Test set, elect. Equip.

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

Yes - demil/mli

Fig:

A310a0