

View Online at <https://aerobasegroup.com/nsn/6625-01-383-1968>

Reliability Indicator:

Not established

Indicator Type:

Dial w/pointer

Installation Design:

Panel

Scale Marking:

0 to 150 pct load

Features Provided:

Zero adjuster

Phase:

Single

Special Markings:

Red band at 100 to 150 pct

Supplementary Features:

Input 0 to 1 ma dc

Fsc Application Data:

Test set, elect. Equip.

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fig:

A310a0