

View Online at <https://aerobasegroup.com/nsn/6625-01-384-4916>

Reliability Indicator:

Not established

Indicator Type:

Dial w/pointer

Installation Design:

Panel

Accuracy In Percent:

-2.0 to 2.0 at full scale single indicator single range

Power Source:

External

Phase:

Single

Fsc Application Data:

Test set, elect. Equip.

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

A310a0