

View Online at <https://aerobasegroup.com/nsn/6625-01-391-2552>

Reliability Indicator:

Not established

Indicator Type:

Dial w/pointer

Installation Design:

Panel

Dial Scale Marking Color:

White single indicator single range

Background Color:

Black single indicator single range

Pointer Color:

White single indicator single range

Power Source:

External

Measurement Range:

-50.0/+50.0 amperes single indicator single range

Features Provided:

Zero adjuster

Phase:

Single

Fsc Application Data:

Test set, elect. Equip.

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fig:

A310a0