

View Online at <https://aerobasegroup.com/nsn/6625-01-400-1567>

Reliability Indicator:

Not established

Indicator Type:

Dial w/pointer

Installation Design:

Bench

Features Provided:

Zero adjuster

Circuit Attachment Method And Quantity:

2 threaded stud

Phase:

Single

Fsc Application Data:

Test set, elect. Equip.

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

A310a0