

View Online at <https://aerobasegroup.com/nsn/6625-01-443-8666>

Reliability Indicator:

Not established

End Application:

Console e/i fscm 06481

Indicator Type:

Dial w/pointer

Scale Marking:

0to100psig0; 20; 40; 60; 80; 100; psig

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

A310a0