

View Online at <https://aerobasegroup.com/nsn/6625-01-446-5473>

Reliability Indicator:

Not established

End Application:

Console e/i fscm 77221

Indicator Type:

Dial w/pointer

Installation Design:

Panel

Power Source:

External

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fig:

A310a0