

View Online at <https://aerobasegroup.com/nsn/6635-00-698-6823>

**Measurement Unit:**

Pound

**Operation Method:**

Manual

**Unit Type:**

Weighing scale

**Load Receiver Type:**

Platform

**Mounting Method:**

Table

**Scale Range:**

0 to 10 lb

**Scale Smallest Increment Graduation:**

0.25

**Spring Type For Which Designed:**

Tension

**Torque Indicating Wrench Usage Feature:**

Not included

**Spring Travel Gage:**

Not included

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fiig:**

T398-h