

View Online at <https://aerobasegroup.com/nsn/6635-01-153-7687>

Scale Calibration:

0 to 20 degrees angular deflection

Measurement Unit:

Ounce

Operation Method:

Manual

Unit Type:

Weighing scale

Load Receiver Type:

Rod

Mounting Method:

Portable

Scale Range:

0 to 16 oz

Scale Smallest Increment Graduation:

4 oz smallest increment

Spring Type For Which Designed:

Compression and tension

Torque Indicating Wrench Usage Feature:

Not included

Spring Travel Gage:

Not included

Special Features:

Bidirectional dial

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

T398-h