

View Online at <https://aerobasegroup.com/nsn/6635-01-418-8295>

Mounting Type:

Floor

Current Type:

Ac

Prime Mover Horsepower Rating:

30.0

Drive Type:

Belt

Angular Unbalance Location Method:

Any acceptable

Maximum Working Weight Capacity:

1500.0 pounds

Minimum Working Weight Capacity:

50.0 pounds

Maximum Distance Between Bearing Shoulders:

106.000 inches

Work Support Type:

Roller

Err Default:

Err default

Integral Correction Drilling Attachment:

Not included

Voltage In Volts:

460.0

Phase:

Three

Special Features:

Multiweight balance correction software if required to correct unbalance situation

Frequency In Hertz:

60.0

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

T137-e