

View Online at <https://aerobasegroup.com/nsn/6635-01-418-8295>

**Mounting Type:**

Floor

**Current Type:**

Ac

**Prime Mover Horsepower Rating:**

30.0

**Drive Type:**

Belt

**Angular Unbalance Location Method:**

Any acceptable

**Maximum Working Weight Capacity:**

1500.0 pounds

**Minimum Working Weight Capacity:**

50.0 pounds

**Maximum Distance Between Bearing Shoulders:**

106.000 inches

**Work Support Type:**

Roller

**Err Default:**

Err default

**Integral Correction Drilling Attachment:**

Not included

**Voltage In Volts:**

460.0

**Phase:**

Three

**Special Features:**

Multiweight balance correction software if required to correct unbalance situation

**Frequency In Hertz:**

60.0

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fiig:**

T137-e