

View Online at <https://aerobasegroup.com/nsn/6635-01-579-7856>

**Mounting Type:**

Floor

**Current Type:**

Ac

**Prime Mover Horsepower Rating:**

1.0

**Drive Type:**

Belt

**Angular Unbalance Location Method:**

Phase reference

**Product Name:**

Horizontal dyanmic balancing system for drive shafts

**Voltage In Volts:**

120.0 or 230.0

**Phase:**

Single or three

**Functional Classification:**

Aa-8.9

**Frequency In Hertz:**

60.0

**Functional Description:**

Used to balance drive shafts on a lathe type setup to approximately 4000rpm

**Entry Date:**

09-11-16

**Reference Data And Literature:**

Balancemaster manual 85he150sp-003

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

Yes - demil/mli

**Fiig:**

T137-e