

View Online at <https://aerobasegroup.com/nsn/6635-01-579-7856>

Mounting Type:

Floor

Current Type:

Ac

Prime Mover Horsepower Rating:

1.0

Drive Type:

Belt

Angular Unbalance Location Method:

Phase reference

Product Name:

Horizontal dyanmic balancing system for drive shafts

Voltage In Volts:

120.0 or 230.0

Phase:

Single or three

Functional Classification:

Aa-8.9

Frequency In Hertz:

60.0

Functional Description:

Used to balance drive shafts on a lathe type setup to approximately 4000rpm

Entry Date:

09-11-16

Reference Data And Literature:

Balancemaster manual 85he150sp-003

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

Yes - demil/mli

Fiig:

T137-e