

View Online at <https://aerobasegroup.com/nsn/6660-00-574-4179>

**Scale Unit Of Measure Inscription:**

Graduated in knots

**Major Components:**

Anemometer wind vane; spare wind speed transmitter; spare wind vane; carrying case

**Accessory Controlling Agency:**

An

**Accessory Identifying Number:**

Mil-44 (b)/pmq-3 type no. And t-321(b)/pmq-3 type no. And ml-447(b) /pmq-3 type no. And cv1067b/pmq-3 type no.

**Wind Speed Component Operation Method:**

Wind actuated generator

**Wind Direction Component Operation Method:**

Wind vane position read directly on numbered scale

**Dial Type And Range:**

0 to 15, 0 to 60 wind speed indicator

**Shelf Life:**

N/a

**Unit Of Measure:**

--

**Demilitarization:**

No

**Fiig:**

T206-e

**Mil-std (military Standard):**

spec.