

View Online at <https://aerobasegroup.com/nsn/6680-00-099-5661>

Indicator Type:

Dial

Scale Calibration:

E to f

Scale Type:

Stationary

Scale Smallest Increment:

0.125 tank

Mounting Method:

Flange

Float Protective Case:

Not provided

Float Guide Wire:

Not provided

Shelf Life:

N/a

Unit Of Measure:

--

Demilitarization:

No

Fiig:

T179-g