Radio Frequency Transformer - Page 1 of 1



View Online at https://aerobasegroup.com/nsn/5950-00-971-5675

| Reliabilit | Indicator: | |
|------------|---------------------------------------------------|--|
| Not estab | ished | |
| Transfor | ner Function: | |
| Input | | |
| Frequence | y Rating: | |
| 60.0 meg | hertz single component | |
| Adjustme | nt Device Drive Type: | |
| Slotted sc | rew single component | |
| Body Ler | gth: | |
| 0.593 incl | es | |
| Body Out | side Diameter: | |
| 0.250 incl | es | |
| Mounting | Method: | |
| Threaded | bushing single group | |
| Winding | Function And Quantity: | |
| 1 primary | single component and 1 secondary single component | |
| Thready | Qty Per Inch (tpi): | |
| 32 single | group | |
| Thread S | ze: | |
| 0.164 incl | es single group | |
| Adjustme | nt Method And Quantity: | |
| 1 adjustat | le core single component | |
| Thread S | eries Designator: | |
| Unc single | group | |
| Terminal | Type And Quantity: | |
| 8 tab, sol | der lug | |
| Shelf Life | : | |
| N/a | | |
| Unit Of M | easure: | |
| | | |
| Demilitar | zation: | |
| No | | |
| Fiig: | | |
| A058b0 | | |